


# KING OF BOXER



KING OF BOXER ©1985 WOODPLACE INC.

## 図ディスプレイスイッチの設定

●DIP SW.1



内容	スイッチポジション							
	1	2	3	4	5	6	7	8
REST							OFF	OFF
							ON	OFF
							OFF	ON
							ON	ON
DEMO SOUND						OFF		
						ON		
DIFFICULTY				OFF	OFF			
難易度				OFF	ON			
				ON	OFF			
				ON	ON			
図体切換							OFF	
アップライト							ON	
テストモード							OFF	
							ON	

●DIP SW.2

内容	Sw Position							
	1	2	3	4	5	6	7	8
ICoin IPLAY						OFF	OFF	OFF
1 " 2 "						OFF	OFF	ON
1 " 3 "						OFF	ON	OFF
1 " 4 "						OFF	ON	ON
1 " 5 "						ON	OFF	OFF
2 " 1 "						ON	OFF	ON
3 " 1 "						ON	ON	OFF
4 " 1 "						ON	ON	ON
画面停止							OFF	
ストップモード							ON	

## 図コネクター接続図

36Pin P=4mm



基板

## 図操作機能

