


2. Points and methods of adjustment

MDS P.C. Board

Game Option Settings

VS TENNIS



			Switch (SW1) Settings							
			1	2	3	4	5	6	7	8
Difficulty	Easy	1	OFF	OFF						
		2	OFF	ON						
		3	ON	OFF						
		4	ON	ON						
VS. Computer	↓	1								
		2								
		3								
		4								
Difficulty	Easy	1			OFF	OFF				
		2			OFF	ON				
		3			ON	OFF				
		4			ON	ON				
VS. Person	↓	1								
		2								
		3								
		4								
Racket Size	Large					OFF				
	Small					ON				
Extra Score	1 Set						OFF			
	1 Game						ON			
Court Color	Green							OFF		
	Blue							ON		
NINTENDO (TITLE DISPLAY)	JAPAN								OFF	
	USA								ON	

		Switch (SW2) Settings							
		1	2	3	4	5	6	7	8
Game Mode		OFF							
	Test Mode	ON							
Coin/Credit	1/1		OFF	OFF					
	1/2		OFF	ON					
	2/1		ON	OFF					
	FREE		ON	ON					
Game Mode	A				OFF	OFF			
	Refer to				OFF	ON			
	table below				ON	OFF			
	D				ON	ON			
Number of	3						OFF	OFF	
	Rackets						OFF	ON	
	Per Game						ON	OFF	
	2						ON	ON	
Attract	No Music								OFF
	Music								ON

Game Mode	A	B	C	D
Singles (VS · Computer)	1 Credit	1 Credit	1 Credit	1 Credit
Doubles (VS · Computer)	1 Credit	2 Credit	1 Credit	2 Credit
Singles (VS · Person)	2 Credit	2 Credit	2 Credit	2 Credit
Doubles (VS · Persons)	2 Credit	2 Credit	4 Credit	4 Credit